

# AUTOFUSER<sup>®</sup> ELASTOMERIC PUMP

## Infusion Progress Guide for Patients

The following images show various stages of the AutoFuser pump infusion process. *Note: coloured liquid has been used to demonstrate the inflation of the balloon and enhance visibility.*

**1** Pump primed, ready for use



**2** After 6 hours (approx)



**3** After 12 hours (approx)



**4** After 18 hours (approx)



**5** After 30 hours (approx)



**6** After 36 hours (approx)



**7** After 48 hours (approx)



Do not be alarmed if the balloon infuses unevenly - this is quite normal